

# Requirements for Computer Aided Design (CAD) in Hafslund Oslo Celsio

F08	27.05.2022	New Logo Changed Company Name	LANGMET		
F07	25.01.2022	Changed reference in links	LUNDEJOS		
F06	08.01.2021	Chapter 4.1 and 4.4	STUBANJ	ALMQVCAR	LUNDEJOS
F05	30.09.2020	Tilpasset kjøling i tabell 4.2	LUNDEJOS		
F04	09.09.19	Oversatt til engelsk	Ulevaing	Stubanj	
F03	08.09.2017	Diverse endringer	JLU	KRN	ØYN
F02	20.03.2013	Endelig utgave for publisering	JLU	KRN	ØYN
A01	06.03.2013	Til kommentar (høring)	JLU		
REVISJON	DATO	BESKRIVELSE	REVIDERT AV	KONTROLLERT	GODKJENT
		Utarbeidet av: <b>Jostein Lunder</b>		Antall sider: <b>Side: 1 av 9</b>	
		Dokumenteier: <b>Hafslund Oslo Celsio - Varmeplan</b>			
Dokumentnr: ID 102786		Dokumentkode: [Kategori]		Dato: [Publiseringsdato]	
				Revisjon: <b>F08</b>	

# Table of contents

<b>1</b>	<b>DEFINITIONS AND ABBREVIATIONS</b> .....	<b>3</b>
<b>2</b>	<b>PURPOSE</b> .....	<b>3</b>
<b>3</b>	<b>SCOPE</b> .....	<b>3</b>
<b>4</b>	<b>GENERAL REQUIREMENTS FOR DRAWINGS</b> .....	<b>3</b>
4.1	SOFTWARE .....	3
4.2	DRAWING NUMBER .....	4
4.3	FILE NAME .....	4
4.4	CONSTRUCTION AND DESIGN OF THE DRAWING .....	4
4.4.1	GEOGRAPHICALLY RELATED DRAWINGS .....	4
4.4.2	LAYERING.....	5
4.4.3	LINE TYPES .....	5
4.4.4	SYMBOLS .....	5
4.4.5	LAYOUT, PLOT FILES .....	5
4.4.6	RASTER, XREF AND OLE OBJECTS .....	5
4.4.7	FILLING IN TITLE AND REVISION BLOCKS .....	5
<b>5</b>	<b>REVISION OF DRAWINGS</b> .....	<b>7</b>
5.1	REVISION CODES .....	7
5.2	REVISION NUMBER .....	8
5.3	CODING OF EXPIRED DRAWINGS .....	8
<b>6</b>	<b>FINAL DOCUMENTATION, AS BUILT</b> .....	<b>8</b>
<b>7</b>	<b>REFERENCES</b> .....	<b>8</b>

## 1 DEFINITIONS AND ABBREVIATIONS

Term	Definition
<b>CAD</b>	Computer Aided Design
<b>MRM</b>	Management, Regulation and Monitoring
<b>BIM</b>	Building Information Modeling
<b>P&amp;ID</b>	Drawings (flow chart) which show a detailed description of equipment and instrumentation
<b>XREF</b>	Reference files in AutoCAD
<b>WCS</b>	World Coordinate System. The main coordinate system of the drawing
<b>UCS</b>	User Coordinate System. Locally user-defined coordinate system in the drawing that does not affect the main coordinate system of the drawing
<b>DWG</b>	The format of the files in AutoCAD
<b>SCD</b>	System Control Diagram
<b>Process flow diagram</b>	Drawings describing the flow of a process. The process flow diagrams provides an overall overview of the process and does not contain a detailed description of equipment.

## 2 PURPOSE

The purpose with this document is to provide a high-level framework for the preparation of Computer Aided Design. This is to ensure a uniform appearance on Hafslund Oslo Celsio's CAD-drawings and models regardless of who produced them.

## 3 SCOPE

The document contains general requirements for the use of CAD in Hafslund Oslo Celsio. The specification applies to all suppliers who produce/revise drawings and models for Hafslund Oslo Celsio. Regarding engineering tasks, requirements exceeding the contents of this specification may be specified.

## 4 GENERAL REQUIREMENTS FOR DRAWINGS

### 4.1 SOFTWARE

Hafslund Oslo Celsio has standardized on the following software for production of drawings:

Within the electrical field, drawings should be produced in EPLAN Electric P8.

Within the field of automation (SRO), SCDs should be produced in Microsoft Visio.

Process flow diagrams and P&IDs should be produced in AutoCAD P&ID(AutoCAD Plant 3D), see chapter 4.4.

Pipe arrangement/isometric drawings should be produced in "pure" AutoCAD.

In projects where 3D models (BIM) are to be produced, Hafslund Oslo Celsio prefers that the 3D models (BIM) be produced in products from Autodesk, but is not a requirement. If other software is used, the 3D model must be available in IFC format

## 4.2 DRAWING NUMBER

Drawing number should be labelled according to Hafslund Oslo Celsio's series of drawing numbers. Drawing numbers are provided by Hafslund Oslo Celsio in each project on request. Requests are sent to dokvarme@celsius.no with the following information:

The assignment number/project number, the type of drawing category to be produced and the number within each drawing category. For the different drawing categories, see table 4.2 below

Table 4.2

Heat production plant	Distribution network/customer
Common issues	Customer central
Structural engineering	Indoor primary/secondary district heating/cooling pipes
Ventilation, cooling, heating and sanitation of the building	Outdoor primary/secondary district heating/cooling pipes
Piping	Manhole (chamber) primary/secondary network
Electrical and automation	Duct cables
Process flow diagram, P&ID	Alarm
Fire protection	

## 4.3 FILE NAME

All files must be entered with the drawing number first in the file name, followed by an explanatory title.

Example: 131.16-215601 – Process flow diagram Vika heat central district heating system.dwg

## 4.4 CONSTRUCTION AND DESIGN OF THE DRAWING

All drawings produced for Hafslund Oslo Celsio must be produced with Hafslund Oslo Celsio's drawing templates. The templates are located at [Celsio.no](http://Celsio.no) (click on the link to download the zip file with templates).

In model rooms, always draw in actual size (1:1). References should always be made to related drawings in the drawing itself where this is natural.

P&IDs are to be established in CELSIO's Autocad P&ID database. A "BIM360 design" license is required to access AutoCAD P&IDs. The template for P&IDs is located in CELSIO's BIM360 database.

Hafslund Oslo Celsio must be contacted in the initial state of the project to get invited to the environment.

### 4.4.1 GEOGRAPHICALLY RELATED DRAWINGS

For all geographically related drawings, use Euref 89 zone 32 or NTM zone 10 as a coordinate system.

Origo must coincide with Euref origo on the equator.

For AutoCAD drawings this means WCS (World Coordinate System). It is up to anyone to use user-defined coordinate systems (UCS in AutoCAD). These will naturally coincide with buildings' axes or similar. Origo and direction of rotation can be set as it suits at any time, as long as the model is not moved in the world coordinate system.

#### 4.4.2 LAYERING

Layers in the drawings should be organized by having lines, text, targets, symbols and figures on different layers and be drawn only once in the model. The layering should also be of such a character that the various elements can be switched on and off as needed. The layers should have names that make them easy to identify.

#### 4.4.3 LINE TYPES

For line types and line thicknesses, reference is made to NS 8302. For special subject areas, it may be necessary to use other line types or line thicknesses than those described in the standard. The meaning of the lines must then be stated in other standards or explained on the current drawing.

#### 4.4.4 SYMBOLS

Symbols should be placed as blocks in the drawing/model. The symbols should be according to ISO 14617/IEC 60617 (graphical symbols for diagrams) and IEC 61082 (electrotechnical documentation). The symbol library for P&IDs is located in CELSIO's BIM360 with drawing number 241421 (you need access to the environment or the drawing can be sent on request)

The document "Hafslund Oslo Celsio – SCD legend" for SCD (to be sent on request).

#### 4.4.5 LAYOUT, PLOT FILES

Drawings should not be based on CTB-files (plot files) that control the colors of printouts unless the CTB-files are distributed by Hafslund Oslo Celsio.

#### 4.4.6 RASTER, XREF AND OLE OBJECTS

No raster files should be inserted in the drawings. Company logos and such should be drawn and be an integrated part of the drawing. In special cases exceptions may be made, e.g. scanned drawing substrate that is not appropriate to vectorize.

External references (XREF) can be used in the project, but must be linked to the drawing before it is handed over.

Use of OLE objects in drawings must be approved by Hafslund Oslo Celsio unless the OLE objects are already in a drawing template distributed by Hafslund Oslo Celsio.

#### 4.4.7 FILLING IN TITLE AND REVISION BLOCKS

In title and revision blocks, only capital letters should be used.


The blocks must be filled in according to table 4.4.7:

Table 4.4.7

<b>Explanation of the fields in the title field block</b>		
<b>English translation</b>	<b>Norwegian translation</b>	<b>Explanation</b>
Drawing number (in the title field)	Tegning nummer (i tittelfelt)	Enter the drawing number provided by Hafslund Oslo Celsio
Drawing number (in the margin)	Tegning nummer (i marg)	Enter the same drawing number as in the box above
Revision number	Revisjonsnummer	The current revision for the drawing is entered into this field in accordance with chapter 5 Revisions
Title (line 1)	Tittel (linje 1)	Enter the address of the facility in question. Drawings for heat production plants and pumping stations must indicate which "object" applies. (Example: HARALDRUD VARMESENTRAL)
Title (line 2)	Tittel (linje 2)	Enter a descriptive text for the drawing
Title (line 3)	Tittel (linje 3)	Enter the AKS-, KKS- or ISO-number
Title (line 4)	Tittel (linje 4)	This field will describe what the drawing contains, plan, section, profile, P&ID etc.
Title (line 5)	Tittel (linje 5)	Available
Document date (YYYY-MM-DD)	Dok. Dato (ÅÅÅÅ-MM-DD)	Enter the date for the beginning of the drawing. The date format should be: YYYY-MM-DD
Drawn by (case worker)	Tegnet av (Saksbeh)	Enter the initials of the person who has drawn/designed the drawing
Scale	Målestokk	The main scale of the drawing should be indicated when the drawing is plotted out in 1:1
Format	Format	The field is already filled in with the format of the drawing, A1 etc. Do not change this
Substitute for	Erstatning for	If the drawing replaces an old drawing, the old drawing number must be entered here
Consultant	Konsulent	Enter the consultant's company name. This is a hidden attribute in the title field
Project number Hafslund Oslo Celsio	Prosjektnr Hafslund Oslo Celsio	Enter the project number/assignment number specified by Hafslund Oslo Celsio
Work Order Contractor/consultant	Oppdragsnr. Entreprenør/konsulent	Enter the contractor/consultant's assignment number if needed
<b>Explanation of the fields in the revision block</b>		
Revision number	Revisjonsnummer	Enter revision number for the drawing in accordance with chapter 5 Revisions
Revision date (YYYY-MM-DD)	Revisjonsdato (ÅÅÅÅ-MM-DD)	Enter the revision date. The date format should be: YYYY-MM-DD
Revision concern	Revisjon gjelder	Brief description of what changes have been made
Revision drawn by	Revisjon tegnet av	Enter the initials of the person who has drawn/designed the revision of the drawing
Revision approved by	Revisjon godkjent av	Enter the initials of the person who formally approved the revision of the drawing by the executive part

Revision approved date (YYYY-MM-DD)	Revisjon godkjent dato (ÅÅÅÅ-MM-DD)	Enter the date for when the revision of the drawing has been approved. The date format should be: YYYY-MM-DD
-------------------------------------	-------------------------------------	--

Example of a correctly filled in title block:

F02	2013-03-05	SOM BYGGET	JLU	ØYN	2013-03-05
A01	2012-09-20	TIL KOMMENTAR	JLU		
REV.	DATO	REVISJONEN GJELDER	TEGN.	GODKJ.	GODKJ. DATO
		PROSJEKTNR. HAFSLUND VARME	OPPDRAGSNR. ENTREPRENØR/KONS.		
		31E-			
HARALDRUD VARMESENTRAL SYSTEM NATURGASSBRENSSEL 31.V.GV9.EK P&ID			DOK. DATO		
			2012-09-20		
			TEGNET AV		
			JLU		
			MALESTØKK		
			-		
			FORMAT		
			A1		
			ERSTATNING FOR		
		Fortum Oslo Varme AS Postadresse: PB 930 Skeien, 0247 Oslo Besøksadresse: Drammensveien 144 Sentralbord: 22 43 59 80 www.fortumoslovarme.no	TEGNING NR.		REV.
		131.46-215620		F02	

## 5 REVISION OF DRAWINGS

When modifications are made to installations that affect the existing documentation, the documentation must be revised so that it corresponds to reality. Changes to installations may also require new documentation. Hafslund Oslo Celsio considers whether to revise or create new documentation for each project.

Each time drawings are revised, this should be marked by increasing the revision number by one. This is entered in the field Revision number in the title block. In addition should the revision block be re-inserted if there is not one that is "vacant" from the previous drawing. It should be filled in according to chapter 4.4.7. The revision history should always indicate the most recent revision at the top. The revision number consists of a revision code (A-U) and a revision number (01-99), a total of 3 characters.

Changes are marked according to NS 8310 with revision cloud and revision symbol which indicates the revision number. The revision cloud and revision symbol are laid on separate layers (ex. revision-01) and drawn in layout (paperspace). Cloud and symbol will become invisible by the next revision.

### 5.1 REVISION CODES

The following revision codes shall state the purpose of the revision:

- A = Internal edition
- B = Comment from the client (Hafslund Oslo Celsio)
- C = Request for tender or offer
- D = Contract

E = Construction, fabrication (blueprint)  
 F = Final edition (finished), as built  
 U = Expired

## 5.2 REVISION NUMBER

The revision number for a document or drawing is a sequential number that increases by 1 each time a new revision of the document is released. The revision number starts at 01, which is also the first edition of the document. If the revision code changes, the revision number must also change.

Example: A01, B02, C03, D04, E05, E06, F07

## 5.3 CODING OF EXPIRED DRAWINGS

When a drawing or document is deleted, should this be made visible by revision. The new revision shall have revision code U and a new revision number.

Reference should also be made to any documents that replace the old one.

## 6 FINAL DOCUMENTATION, AS BUILT

All final documentation must be submitted in original format + PDF.

For projects documented in EPLAN, this means that a zw1 file must be submitted in addition to a PDF file.

For drawings/models produced in AutoCAD, AutoCAD P&ID and AutoCAD Plant 3D, this means that drawings/models must be delivered in dwg format with all associated databases/libraries for 3D models.

For 3D models (BIM) that are not produced in Autodesk software, this means that the IFC file must be submitted in addition to a PDF file.

On "as-built" drawings, all revision clouds and revision symbols should be removed.

The XREF used must be linked to the completed drawing (in AutoCAD, xbind, eTransmit).

PDF drawings should be properly oriented and show layering (separate function in Acrobat). If the drawing is produced with more than 1 layout (multiple drawings in 1 file), the name of the layout should be equal to the drawing number. It must be "cleaned up" in the drawing before handing it over to Hafslund Oslo Celsio.

By "cleaned up" it means data that is not used in the drawing such as blocks, layers + +, and objects lying around and "hovering" (purge command). When running a Zoom – Extents command, there should be no objects outside the drawing frame in layout.

Drawings/models and other material prepared in a project paid for or managed by the client, is the client's property and must be handed over to Hafslund Oslo Celsio.

## 7 REFERENCES

Document reference	Description
--------------------	-------------



<a href="#">Drawing templates</a> (Norwegian: Tegningsmaler)	Hafslund Oslo Celsio's drawing templates in a zipped folder at Celsio.no
The symbol library and template for P&IDs	Symbol library (drawing number 241421) and template is located in CELSIOs BIM360 environment.
Instruction for district heating development and Instruction for district cooling development (Norwegian: Instruks for fjernvarmeutbygging og Instruks for fjernkjøleutbygging)	Requirements regarding deliveries on distribution networks and customer centrals is located on Fortum.no <a href="https://www.celsio.no/fjernvarme-og-kjoling-for-entreprenorer/">https://www.celsio.no/fjernvarme-og-kjoling-for-entreprenorer/</a>
Hafslund Oslo Celsio – SCD legend	Template for System Control Diagram (will be sent on request)